



# Adjustable Front Mount Instructions

Upper Ring

Rotate adjustment sleeve left to increase elevation.



Loosen side clamp screw before adjusting mount.



Each line on the scale is .025

Each line on the adjustment sleeve is .001", one turn is .025"

# #2 Rear Mount

